TRUE/FALSE

		10 bits	to represent 12	.o uiiie	rent characters.		
	ANS: F	PTS:	1	REF:	42		
2.	Infrared light interfer	es with	t affected by radio signals.				
	ANS: F	PTS:	1	REF:	46		
3.	The height of a radio wave is called the amplitude of the wave.						
	ANS: T	PTS:	1	REF:	57		
4.	4. Spread-spectrum signals are more susceptible to outside interference than narrow-band tran						
	ANS: F	PTS:	1	REF:	68		
5.	 Hopping codes used in FHSS transmissions are configured on the base station by the network administrator. 						
	ANS: F	PTS:	1	REF:	69		
MUL	ГІРЬЕ СНОІСЕ						
1.	Which of the following a. they travel at the b. they require an at	speed o	of light	c.	signal transmissions? they travel as discrete particles they require visible light		
		DTC		DEE			
	ANS: A	PTS:	1	REF:	43		
2.	ANS: A Which of the following a. it can be used in a b. it can be used in a	ng is NO	OT true about in transmissions	nfrared c.	light? it is less susceptible to interference from visible light sources		
2.	Which of the following a. it can be used in	ng is NO	OT true about in transmissions transmissions	nfrared c. d.	light? it is less susceptible to interference from		
2.	Which of the following a. it can be used in a b. it can be used in a	ng is NO directed diffused PTS:	OT true about in transmissions transmissions	nfrared c. d. REF:	light? it is less susceptible to interference from visible light sources all infrared signals are invisible 44-45 rared device?		
	Which of the following a. it can be used in a b. it can be used in a can b	ng is NO directed diffused PTS:	OT true about in transmissions transmissions 1 mits a signal in	nfrared c. d. REF:	light? it is less susceptible to interference from visible light sources all infrared signals are invisible 44-45 rared device? detector antenna		
	Which of the following a. it can be used in a b. it can be used in a ANS: D Which of the following a. diffuser b. emitter ANS: B	ng is NO directed diffused PTS: ng trans PTS:	OT true about in transmissions I transmissions 1 mits a signal in	nfrared c. d. REF: an infi c. d. REF:	light? it is less susceptible to interference from visible light sources all infrared signals are invisible 44-45 rared device? detector antenna 45 rg infrared wireless systems? someone can eavesdrop from another		
3.	Which of the following a. it can be used in a b. it can be used in a can b	ng is NO directed diffused PTS: ng trans PTS: ng is NO	OT true about in transmissions I transmissions 1 mits a signal in 1 OT a limitation	d. REF: an infi c. d. REF: of usin c.	light? it is less susceptible to interference from visible light sources all infrared signals are invisible 44-45 rared device? detector antenna 45 g infrared wireless systems?		

5.	Which of the followi a. stream movies fr b. wireless outdoor	om a server		for an infrared wireless system? c. whole house wireless network d. data transfer between laptop and camera		
	ANS: D	PTS: 1	REF:	47		
6.	Which best describes a. it starts and stops b. intensity varies a	s and is continuous	c. d.	consists of discrete pulses Morse code is an example		
	ANS: B	PTS: 1	REF:	50		
7.	What process must o a. modulation b. decoupling	ccur to transmit		ol over an analog medium? decoding emitting		
	ANS: A	PTS: 1	REF:	51		
8.	The distance between which of the following a. amplitude b. wavelength	-	c.	d the same point in the next wave cycle is called carrier frequency		
	ANS: B	PTS: 1	REF:	51		
9.	The frequency of a wa. encoding of bits b. the voltage differ and trough of the	onto an analog v rence between th	wave c.	of the following? a carrier wave that has been modulated the number of times a cycle occurs within one second		
	ANS: D	PTS: 1	REF:	52		
10.	What is the unit of ma. volt b. rpm	easurement for	_	ey? Hz amp		
	ANS: C	PTS: 1	REF:	53		
11.	What is the role of an a. it receives data b. it demodulates	ı antenna on a w	c.	? it serves as a ground signal it transmits and receives data		
	ANS: D	PTS: 1	REF:	54		
12.	Which of the followia. only one bit can unit (baud)b. multiple bits can signal unit	be transferred po	er signal c.	a baud rate of 2400 always means a bandwidth of 2400 bps multiple signal units are needed to represent each bit		
	ANS: B	PTS: 1	REF:	55		
13.	Which of the following a. the range of frequency transmitted by a	uencies that can		n an analog system? the number of bytes transmitted per minute		

	b. t	the number of b	its transı	mitted per secon	nd d.	the maximum frequency supported by the medium
	ANS	S: A	PTS:	1	REF:	56
14.	a. p	ch of the follow phase carrier	ing is N	OT a type of m	c.	on that can be applied to an analog signal? frequency amplitude
	ANS	S: B	PTS:	1	REF:	57
15.	a. 1	AM	signal is	s most suscepti	c.	m interference sources such as lightning? PM
	b. 1					DM
	ANS	S: A	PTS:	1	REF:	57
16.	a. ł	ch of the follow better use of bar requires less pov	ndwidth	OT an advantaş	c.	gital modulation over analog modulation? better performance during interference modulation techniques are simpler
	ANS	S: D	PTS:	1	REF:	61
17.	the b	ch binary signal bit period ends. NRZ-L NRZ-I	ing tech	nique reduces t	c.	age to zero during the transmission of a 1 bit before RZ NRZ
	ANS	S: C	PTS:	1	REF:	61
18.		ch binary modu esents a 0 bit?	lation te	chnique employ	ys NRZ	Z coding such that the absence of a carrier signal
		ASK BPSK				FSK PSK
	ANS	S: A	PTS:	1	REF:	64
19.	a. l	ch radio transm FM FHSS	ission m	ethod uses a ch	c.	code? DSSS AM
	ANS		PTS:	1	REF:	
20.		ch of the follow ver lost data bits		spread spectrum	n techn	ique that employs mathematical algorithms to
		frequency hoppi direct sequence	ing			narrow band wide band
	ANS	S: B	PTS:	1	REF:	74
СОМ	PLET	ΓΙΟΝ				
1.	Data	signals in a wi	reless co	mmunication s	ystem t	cravel on waves.
	ANS	S: electromagne	etic			

	PTS:	1	REF:	43	
2.	A sign	al that is broad	cast as	a continuous wave is called a(n)	signal.
	ANS:	analog			
	PTS:	1	REF:	49-50	
3.		representing a	wave w	rith a garden hose, the distance between the peaks of	f the waves represents
	ANS:	wavelength			
	PTS:	1	REF:	51	
4.	The _ a posit	ive value and a	non- 10 bit b	return-to-zero encoding method represents a 1 bit by decreasing the voltage to a negative value.	y increasing voltage to
	ANS:	polar			
	PTS:	1	REF:	62	
5.		presence of bac frequency or a		nd interference, receivers can detect ae change.	_ change more reliably
	ANS:	phase			
	PTS:	1	REF:	67	

MATCHING

a. ASCII
b. amplitude modulation
c. analog signal
d. hopping code
d. baud rate
e. carrier signal
f. digital modulation
g. frequency modulation
h. hopping code
i. NRZ
j. PM

- 1. a method of encoding a digital signal onto an analog carrier wave for transmission over media that does not support direct digital signal transmission
- 2. the number of times that a carrier signal changes per second
- 3. a technique that changes the number of wave cycles in response to a change in the amplitude of the input signal
- 4. a binary signaling technique that increases the voltage to represent a 1 bit but provides no voltage for a 0 bit
- 5. a technique that changes the height of a carrier wave in response to a change in the height of the input signal
- 6. a signal of a particular frequency that is modulated to contain either analog or digital data
- 7. a technique that changes the starting point of a wave cycle in response to a change in the amplitude of the input signal
- 8. the sequence of changing frequencies used in FHSS
- 9. a coding scheme that uses the numbers from 0 to 127 to represent alphanumeric characters and symbols

10. a signal in which the intensity (amplitude or voltage) varies continuously and smoothly over a period of time

1.	ANS:	F	PTS:	1	REF:	76,60
2.	ANS:	D	PTS:	1	REF:	76,55
3.	ANS:	G	PTS:	1	REF:	76,58
4.	ANS:	I	PTS:	1	REF:	77,62
5.	ANS:	В	PTS:	1	REF:	75,57
6.	ANS:	E	PTS:	1	REF:	76,52
7.	ANS:	J	PTS:	1	REF:	77,59
8.	ANS:	H	PTS:	1	REF:	76,69
9.	ANS:	A	PTS:	1	REF:	75,42
10.	ANS:	C	PTS:	1	REF:	75,50

SHORT ANSWER

1. Describe the components in an infrared wireless system.

ANS:

Infrared wireless systems require that each device have two components: an emitter, which transmits a signal, and a detector, which receives the signal. (These two components are almost always combined into one device.) An emitter is usually a laser diode or a light emitting diode (LED). Infrared wireless systems send data by the intensity of the light wave instead of whether the light signal is on or off. To transmit a 1, the emitter increases the intensity of the electrical current and, consequently, the intensity of the infrared light, which indicates a pulse to the receiver. The detector senses the higher-intensity pulse of light and produces a proportional electrical current

PTS: 1 REF: 45

2. What are the advantages and limitations of an infrared wireless system?

ANS:

Infrared wireless systems have several advantages. Infrared light neither interferes with other types of communications signals (such as radio signals) nor is it affected by other signals, except light. In addition, because infrared light does not penetrate walls, the signals are kept inside a room. This makes it impossible for someone elsewhere to listen in on the transmitted signal.

However, there are several serious limitations to infrared wireless systems. The first limitation involves the lack of mobility. Directed infrared wireless systems use a line-of-sight principle, which makes it challenging for mobile users because the alignment between the emitter and the detector would have to be continually adjusted. The second limitation is the range of coverage. Directed infrared systems, which require line of sight, cannot be placed in an environment where there is the possibility that anything could get in the way of the infrared beam (think of someone standing in front of your remote control while you are trying to change TV channels). This means that devices using infrared transmissions must be placed close enough to one another to eliminate the possibility of something moving between them. Due to the angle of deflection, diffused infrared can cover a range of only 50 feet (15 meters). And because diffused infrared requires a reflection point, it can only be used indoors. These restrictions limit the range of coverage.

Another significant limitation of an infrared system is the speed of transmission. Diffused infrared can send data at maximum speeds of only 4 Mbps. This is because the wide angle

of the beam loses energy as it reflects. The loss of energy results in a weakening signal. The weak signal cannot be transmitted over long distances, nor does it have sufficient energy to maintain a high transmission speed, resulting in a lower data rate.

PTS: 1 REF: 46-47

3. Contrast analog signals with digital signals.

ANS:

An analog signal is one in which the intensity of the waves (voltage or amplitude) varies and is broadcast continuously—in other words, the signal has no breaks in it. A digital signal consists of discrete or separate pulses, as opposed to an analog signal, which is continuous. A digital signal has numerous starts and stops throughout the signal stream—Morse code, for example, with its series of dots and dashes.

PTS: 1 REF: 50

4. Describe how radio transmitters use a carrier signal.

ANS:

Radio transmitters send what is known as a carrier signal. This is a continuous wave (CW) of constant amplitude (measured in volts) and frequency. This is essentially an up-and-down wave called an oscillating signal or a sine wave. A CW carries no useful information by itself. Only after it is modulated does it contain some kind of information signal, such as music, voice, or data; then, it is correctly called a carrier signal or carrier wave. A receiver is adjusted (or tuned) to the frequency of the carrier, and it ignores all the other frequencies.

PTS: 1 REF: 52

5. How are radio waves transmitted using an antenna?

ANS:

Radio waves are usually transmitted and received using an antenna. An antenna is a length of copper wire, or similar material, with one end free and the other end connected to a receiver or transmitter. When transmitting, the radio waves created by the electronic circuit of the transmitter are fed to this antenna wire. This sets up an electrical pressure (voltage) along the wire, which will cause a small electrical current to flow into the antenna. Because the current is alternating, it flows back and forth in the antenna at the same frequency as the radio waves. When the electricity moves back and forth in the antenna at the same frequency as the radio waves, it creates both a magnetic field and an electrical field around the antenna. This continuous (analog) combination of magnetism and electrical pressure moves away (propagates) from the antenna the same way that water waves move away from the point of impact when you throw a rock in a pond. The result is an electromagnetic wave (EM wave).

PTS: 1 REF: 54

6. What are the three types of modulation that can be applied to an analog signal to enable it to carry information?

ANS:

The height of the signal, the frequency of the signal, and the relative starting point, or phase, of the signal.

PTS: 1

7. Describe amplitude modulation.

ANS:

The height of a wave, known as the amplitude, can be measured in volts (electrical pressure). In amplitude modulation (AM), the height of the wave is changed in accordance with the height of another analog signal, called the modulating signal. In the case of an AM radio station, the modulating signal is the voice of the announcer or the music, which is also an analog signal. The carrier wave's frequency and phase remain constant.

PTS: 1 REF: 57

8. Describe the NRZ technique of representing bit signals.

ANS:

With non-return-to-zero, the voltage signal remains positive (high) for the entire length of the bit period. In addition, if the next bit to be transmitted is the same as the previous bit, the signal does not change, remaining high for a 1 and low (0 volts or no voltage) for a 0. This effectively reduces the number of signal transitions (baud) required to transmit the message. As with RZ, there is no voltage when transmitting a 0 bit

PTS: 1 REF: 62

9. What is phase shift keying? Describe how it works.

ANS:

Phase shift keying (PSK) is a binary modulation technique, similar to phase modulation, in which the transmitter varies the starting point of the wave. The difference is that the PSK signal starts and stops because it is a binary signal. Whenever a bit being transmitted changes from 1 to 0 (or 0 to 1), the starting point (i.e., the direction of the wave) changes.

PTS: 1 REF: 66

10. How are bits transmitted using DSSS? Include the chipping code in your answer.

ANS:

DSSS uses an expanded redundant code to transmit each data bit and then a modulation technique such as quadrature phase shift keying (QPSK). This means that a DSSS signal is effectively modulated twice. Instead of simply encoding these two bits over a carrier wave for transmission, the value of each data bit is first added to each individual 1 and 0 in a sequence of binary digits called a Barker code. A Barker code (or chipping code) is a particular sequence of 1s and 0s that has properties that make it ideal for modulating radio waves as well as for being detected correctly by the receiver. These 1s and 0s are called chips- instead of bits to avoid confusing them with the actual data bits. The chipping code is sometimes called a pseudorandom code because it is usually derived through a number of mathematical calculations as well as through practical experimentation.

PTS: 1 REF: 72