## TRUE/FALSE

1.	The prefix <i>kilo</i> - repr	resents 1,000 times larger.	•	
	ANS: T	PTS: 1		
2.	In construction, the to	erm <i>plumb</i> is used to indi	icate	that which is horizontal.
	ANS: F	PTS: 1		
3.	Bench planes are give	en names according to the	eir le	ngth.
	ANS: T	PTS: 1		
4.	Ripsaws are designed	I to cut across the grain of	flum	ber.
	ANS: F	PTS: 1		
5.	The Phillips screwdri	ver has a cross-shaped tip	).	
	ANS: T	PTS: 1		
6.	The fractions 12/16 a	nd 24/32 are the same val	lue.	
	ANS: T	PTS: 1		
7.	Square is a term used	to describe a surface that	is p	erfectly vertical
	ANS: F	PTS: 1		
8.	The method of marki	ng a piece to be cut and fi	itted	an irregular surface is called wing dividing.
	ANS: F	PTS: 1		
9.	When driving nails, t	he angle and placement of	f the	nails are important.
	ANS: T	PTS: 1		
10.	Masonry nails and ot often break.	her hardened steel items a	ire sa	afe to drive with a hammer because they do not
	ANS: F	PTS: 1		
MUL	TIPLE CHOICE			
1.	A is 1/100 of a a. micron b. millimeter	meter.	c. d.	centimeter decimeter
	ANS: C	PTS: 1		

2.	Most rules and tapes used by the carpenter have increments of inches, clearly marked in red, and 19.2 inches, indicated by small black diamonds.					
	a. 6 b. 8			12 16		
	ANS: D	PTS: 1				
3.	The square corbody of the square. a. combination b. speed	nsists of a movable	c.	th wide and 12 in framing bevel	inches long, that slides along the	
	ANS: A	PTS: 1				
4.	The carpenter's a. rule b. level	is used to test both	c.	plumb surfaces plumb bob steel tape		
	ANS: B	PTS: 1				
5.	Long straight lines a a. line b. gauge	re laid out by using	c.	 marker rule		
	ANS: A	PTS: 1				
6.	is the techniqua. Dividing b. Etching	e of laying out stock	c.	nst an irregular Fastening Scribing	surface.	
	ANS: D	PTS: 1				
7.	The wood is use a. hatchet b. bevel ANS: C	sed to cut recesses in PTS: 1	c.	things such as of chisel saw	door hinges and locksets.	
8.	The plane is 14 a. jack b. jointer	4 inches long and of	c.	fore smooth	nsidered the best for all-around work.	
	ANS: A	PTS: 1				
9.	planes are sma a. Scrub b. Router	ll planes designed t	c.	n one hand. Block Shoulder		
	ANS: C	PTS: 1				
10.	When starting to pla a. handle b. toe	ne, push forward w	c.	ng pressure dow lever cap heel	vnward on the (front).	
	ANS: B	PTS: 1				

11.	To produce a keen ed whetstone.	lge, chisels and plane iron	ast be (sharpened) by using an oilstone or				
	<ul><li>a. tempered</li><li>b. annealed</li></ul>			compacted whetted			
	ANS: D	PTS: 1					
12.	snips are used to cut thin metal, such as roof flashing and metal roof edging.						
	<ul><li>a. Aluminum</li><li>b. Tin</li></ul>			Copper Steel			
	ANS: B	PTS: 1					
13.	A knife is a uni a. flexible	versal cutting tool.					
	<ul><li>a. flexible</li><li>b. Bowie</li></ul>			utility Swiss			
	ANS: C	PTS: 1					
14.	The crosscut saw has teeth shaped like						
	<ul><li>a. knives</li><li>b. chisels</li></ul>			wedges planes			
	ANS: A	PTS: 1					
15.	The saw is use a. shark tooth	d to make curved cuts.	0	dovetail			
	b. veneer			compass			
	ANS: D	PTS: 1					
16.		sed to cut thin material suc		metal. Hacksaws			
	<ul><li>a. Coping saws</li><li>b. Wallboard saws</li></ul>			Keyhole saws			
	ANS: C	PTS: 1					
17.		ved claw hammer is most p	_				
	a. 7 b. 16			20 32			
	ANS: B	PTS: 1					
18.	is the technique of driving nails at an angle to fasten the end of one piece to another.  a. Face nailing  c. Side nailing						
	<ul><li>a. Face nailing</li><li>b. Skewed nailing</li></ul>			Toenailing  Toenailing			
	ANS: D	PTS: 1					
19.	The is used to withdraw large nails and to a. slotted screwdriver			•			
	<ul><li>a. slotted screwdriv</li><li>b. flat bar</li></ul>	CI		wrecking bar cat's paw			
	ANS: C	PTS: 1					
20.	are hardwood b	clocks with threaded rods t	hrou c.	~			
			٠.	-LD 610111.hp			

b. C clamps

d. Quick clamps

ANS: A

PTS: 1